




# DIY BOOTH

WHATS INCLUDED



RING LIGHT AND BOOTH SYSTEM

TRIPOD

WIFI DONGLE

FABRIC WRAP

POWER ADAPTERS



# ASSEMBLE THE TRIPOD





TAKE THE FABRIC AND WRAP  
HOOP AROUND THE LOWER STEM




## WRAPPING THE UNIT





## ADJUSTING FABRIC

NOW THE WRAP IS AROUND THE TRIPOD ADJUST THE HEIGHT TO SUIT GUESTS AND INCREASE FABRIC TENSION





ATTACH THE RINGLIGHT BY  
SLIDING IT OVER THE STEM






PLUG WIFI DONGLE INTO A WALL SOCKET AND  
TURN ON BY HOLDING  
THE POWER BUTTON DOWN FOR A FEW SECONDS





## PLUG THE RINGLIGHT IN



### TROUBLESHOOTING


THE RINGLIGHT AND IPAD SHOULD IMMEDIATELY ILLUMINATE AS SOON AS ITS PLUGGED IN. IF NOT CHECK THE FOLLOWING SWITCHES ARE TURNED ON








OPEN THE PHOTO BOOTH  
SOFTWARE





## SELECT YOUR EVENT FROM THE LEFT MENU AND CLICK LAUNCH EVENT

IMPORTANT! ONLY SELECT YOUR EVENT AS ANY OTHER WILL NOT HAVE BEEN CONFIGURED CORRECTLY





## IMPORTANT SETTINGS FOR UNINTERRUPTED USE

DUE TO THE PHOTOBOOTH USING AN IPAD IT IS POSSIBLE FOR USERS TO ACCIDENTALLY SWITCH OUT OF THE SOFTWARE. TO PREVENT THIS AND ENSURE THE SMOOTH RUNNING OF THE SOFTWARE YOU SHOULD PRESS THE HOME BUTTON QUICKLY **THREE TIMES IN A ROW** TO ENABLE 'GUIDED ACCESS'. WHEN SUCCESSFUL A NOTIFICATION WILL APPEAR.

TO EXIT THE SOFTWARE AT THE END OF YOUR EVENT PRESS THE HOME BUTTON QUICKLY THREE TIMES IN SUCCESSION THEN ENTER THE PASSWORD: **123456** AND CLICK 'END'.

LASTLY WE ALSO RECOMMEND LOCKING THE PHOTO BOOTH SETTINGS FROM YOUR GUESTS. TO DO THIS CLICK THE TOP RIGHT DROPDOWN BUTTON AND CLICK LOCK. AT THE END OF THE EVENING REPEAT THE PROCESS WITH THE PASSWORD **1234**.

